


Measuring Guide for Custom Cornices

Tools and Tips

- Steel tape measure — do not use cloth tape
- Pencil
- Round measurements to the nearest 1/8"

1/8"
1/4"
3/8"
1/2"
5/8"
3/4"
7/8"



Choose a Mount Type: Inside Mount or Outside Mount

Inside Mount




Figure 1




Figure 2






Figure 3



- 1 Measure window width including molding. Maximum available width is 168" (figure 1).
- 2 Add any additional width desired, especially if hanging curtain panels or sheers under cornice. Round up to nearest full inch (figure 2).
- 3 Cornice returns measure 1 1/4" on each side. Finished front dimension of cornice will measure 2 1/2" wider than your specified width (figure 3). Please take this into consideration if you have two windows close to each other or windows in a corner.

Outside Mount

- 1 Measure the exact width of the window opening at the very top of the casing.
- 2 Measure the exact width of the window opening either 8" or 12" from top, depending on the desired drop of cornices being ordered.
- 3 Measure twice and document the smaller dimension, as not all window openings are perfectly square.



Installation Brackets

Finished Width	Number of brackets
20" – 40"	2
40 1/16" – 76"	3
76 1/16" – 112"	4
112 1/16" – 148"	5
148 1/16" – 168"	6