


Measuring Guide for Decorative Wood Valances

Tools and Tips

- **Steel tape measure** — do not use cloth tape
- **Pencil**
- **Round measurements to the nearest 1/8"**



Choose a Mount Type: **Inside Mount or Outside Mount**

Inside Mount: Flush Window treatments are installed completely inside the window casing.




Flush Mount

An **Inside Mount Decorative Wood Valance** is manufactured with straight-cut edges on both ends and looks best when it is mounted flush to the window casing. The valance width is determined by the width of the window treatment ordered.

Use the chart on the following page to determine if your window is deep enough for a Full Recess Inside Mount Decorative Wood Valance. No further measuring is required.

Inside Mount: Partial Recess Window treatments extend beyond the window casing.



Partial Recess
Exposed Straight Cut Edge




Partial Recess
Valance with Returns

An **Inside Mount Decorative Wood Valance** is manufactured with straight-cut edges on both ends. The valance width is determined by the width of the window treatment ordered.

Depending how far the valance extends beyond the window casing, returns (side pieces) can be ordered to cover the ends of the valance for a more finished look.

Use the chart and instructions on the following page to determine the special valance return length needed, if necessary. Valance returns are available from 1/2" to 8".



A: Inside Measurement
B: Outside Measurement

Outside Mount: Window treatments are installed outside the window casing.



An **Outside Mount Decorative Wood Valance** is manufactured with standard returns (side pieces) sized to cover the ends of the valance to the mounting surface. See chart on the following page for standard outside mount return lengths. If your Outside Mount Valance requires longer returns, please specify at the time of order.

Note: Returns are measured and cut from the **INSIDE** of the miter to ensure the most accurate fit.

For an **Outside Mount Decorative Wood Valance** ordered separately (without a blind or shade):

- 1. Measure Valance Width:** Measure the width to be covered. Maximum width is 193".
Make sure that you have enough space on all sides of your walls to mount your valance.
- 2. Measure for Clearance:** Add additional space for clearance for under treatments (i.e. drapery), mounting brackets and operating controls. **Note:** Valance profile sizes vary by style.
- 3. Measure Valance Return Length:** Measure the distance your valance will extend from the mounting surface and record measurement as your special return length.

Note: If Decorative Wood Valance is not being installed over a window treatment, the backside measurements of the valance and returns will be the exact sizes ordered. No deductions will be taken.


Follow these steps to determine a special valance return length (if necessary):

- Select your product type and valance style and locate the **FULL RECESS DEPTH** column.
- Measure the depth of your window casing. If the depth is less than the Full Recess Depth measurement, consider ordering returns.
- To determine the valance return length, subtract your depth measurement from the Standard Return Length.
- The difference is the size of the valance return length you should order.


Valance Return Information

| Product Type and Valance Style | Standard Return Inside Width | Full Recess Depth | | |
|--|---------------------------------|-----------------------------------|-----------------------------------|----------------------------------|
| SHEER ENCHANTMENT® VERTICAL BLINDS* | | | | |
| 4" Classic Wood Valance | 6¼" | 6 ¹¹ / ₁₆ " | | |
| 4" Curved Wood Valance | 6¼" | 7 ³ / ₁₆ " | | |
| 4½" Eloquence Wood Valance | 6¼" | 7 ¹ / ₁₆ " | | |
| OTHER VERTICAL BLINDS | | | | |
| 4" Classic Wood Valance | 5½" | 5 ¹⁵ / ₁₆ " | | |
| 4" Curved Wood Valance | 5½" | 6 ⁷ / ₁₆ " | | |
| 4½" Eloquence Wood Valance | 5½" | 6¼" | | |
| ROMAN, PLEATED, CELLULAR AND SOLAR/ROLLER SHADES | | | | |
| 4" Classic Wood Valance | 3¾" | 4 ³ / ₁₆ " | | |
| 4" Curved Wood Valance | 3¾" | 4 ¹¹ / ₁₆ " | | |
| 4½" Eloquence Wood Valance | 3¾" | 4½" | | |
| NATURAL SHADES | | | | |
| 4" Classic Wood Valance | 3 ⁵ / ₈ " | 4 ¹ / ₁₆ " | | |
| 4" Curved Wood Valance | 3 ⁵ / ₈ " | 4 ⁹ / ₁₆ " | | |
| 4½" Eloquence Wood Valance | 3 ⁵ / ₈ " | 4 ³ / ₈ " | | |
| VERTICELL™* | | | | |
| 4" Classic Wood Valance | 3 ¹ / ₈ " | 3 ⁹ / ₁₆ " | | |
| 4" Curved Wood Valance | 3 ¹ / ₈ " | 4 ¹ / ₁₆ " | | |
| 4½" Eloquence Wood Valance | 3 ¹ / ₈ " | 3 ⁷ / ₈ " | | |
| 2" HORIZONTAL BLINDS (WOOD, FAUX WOOD, COMPOSITE, ALUMINUM AND VINYL)* | | | | |
| | Cord | Wand | Cord | Wand |
| 4" Classic Wood Valance | 2 ⁷ / ₈ " | 3 ⁹ / ₁₆ " | 3 ⁵ / ₁₆ " | 4" |
| 4" Curved Wood Valance | 2 ⁷ / ₈ " | 3 ⁹ / ₁₆ " | 3 ¹³ / ₁₆ " | 4½" |
| 4½" Eloquence Wood Valance | 2 ⁷ / ₈ " | 3 ⁹ / ₁₆ " | 3 ⁵ / ₈ " | 4 ⁵ / ₁₆ " |
| 2³/₈" & 2½" HORIZONTAL BLINDS* (WOOD, FAUX WOOD AND COMPOSITE)* | | | | |
| 4" Classic Wood Valance | 3¾" | 4 ³ / ₁₆ " | | |
| 4" Curved Wood Valance | 3¾" | 4 ¹¹ / ₁₆ " | | |
| 4½" Eloquence Wood Valance | 3¾" | 4½" | | |
| SLIDING PANELS | | | | |
| 4" Classic Wood Valance | 5" | 5 ⁷ / ₁₆ " | | |
| 4" Curved Wood Valance | 5" | 5 ¹⁵ / ₁₆ " | | |
| 4½" Eloquence Wood Valance | 5" | 5¾" | | |

Eloquence – Outside Mount




Eloquence – Inside Mount



Curved Wood – Outside Mount



Curved Wood – Inside Mount



Classic Wood – Outside Mount



Classic Wood – Inside Mount



*Valances will be attached directly to the headrail of these window treatments.

For all other products, valances will be installed independently from the blind or shade.