

Measuring Guide for Classic Roman Shades

Double-check your work—always measure twice to ensure accuracy.

Tools and Tips

- Steel tape measure — do not use cloth tape
- Pencil
- Round measurements to the nearest 1/8"

Measuring Guidelines

Measuring for an Inside Mount

<p>Inside Mount: Window treatments are installed inside the window casing.</p> <p>Use a steel tape measure for taking measurements.</p>	<p>1. Measure Depth: See chart below to determine if window casing has enough depth for an inside mount window treatment.</p>	<p>2. Measure Width: Measure the inside width of window casing in three places; record narrowest measurement.</p>	<p>3. Measure Length: Measure the inside length from the top of window casing to the top of the sill in three places; record longest measurement.</p>
--	--	--	--

NOTE: Do not take any deductions for clearance. The manufacturer will take necessary deductions for a perfect fit.

Measuring for an Outside Mount

<p>Outside Mount: Window treatments are installed outside the window casing.</p> <p>Use a steel tape measure for taking measurements.</p>	<p>1. Determine Headrail Location: Determine if headrail will be on molding or above molding and mark the spot.</p>	<p>2. Measure Width: Measure exact width to be covered; we recommend 1/2" overlap on each side of the window (3" total) for optimum light control and privacy; record measurement.</p>	<p>3. Measure Length: Measure exact length to be covered, including desired overlap (typically from 1" above the molding to bottom of sill or apron); record measurement.</p>
--	--	---	--

NOTE: The manufacturer makes no deductions on outside mount installations.

Depth Requirements for Inside Mount

Control Type	Fabric Style	Partially recessed headrail in window casing/molding Minimum Headrail Depth Mount (inches)		Fully recessed headrail in window casing/molding Headrail Flush with Casing (inches)	
Standard Cordless Lift	Looped	4 7/8"	3/4"		
	Flat	1 7/8"			
Bottom Up/Top Down	Looped	4 7/8"	3/4"		
	Flat	1 7/8"			
Cordless Lift	Looped	5 1/8"	1/2"		
	Flat	2 1/8"			
Continuous-Loop Lift	Looped	5 1/8"	1/2"		
	Flat	2 1/8"			